

TECHNICAL BULLETIN

MAINTENANCE :

- Attach dust-cover to the detector during the work in the building to prevent the invasion of dust or paint and malfunction of detector.
- During the scheduled maintenance, use the testing device to check the detector whether or not it is in good shape.
- When the repair is needed please return the defect device to manufacturer.

SERVICING TESTS :

- Check two sides of iron-plate under the detector head whether or not they are well conducted.
If fault alarm happened regularly, check the environment for affected factors such as smoke or other heat sources.
- Malfunctioned circuit could not be fixed if it is caused by water leaking.
- If detector has no response all the time, it might be the burning of PCB, low sensitivity or decay of detector. Defective detector should sent back to the manufacturer for repairing and calibration.
- If the identification lamp does not lit while detector is operating, the LED or PCB might be burned and both of them need to be fixed in the factory.

AVOID THESE LOCATIONS


Do Not Locate Your Detector in :

- Front of forced air ducts used for heating and air conditioning and other higher air flow area.
- Height of installation surface is more than 20 meters.
- Dusty area.
- Areas where temperature may fall below 40°F or rise above 100°F.
- Near electrical lights. "WARNING"-Connect Detector Only To Control Unit Initiating Device Circuit As Specified In Detector Or Control Unit Literature Or System May Not Operate.


INSTALLATION INSTRUCTION

WIRING DIAGRAM :

2-Wire Type :




3-Wire Type :




4-Wire Type : (Relay Output)

Contact Rating 0.8A@30V DC 0.4A@125V AC



Caution : Do not connect loop wires at same point to prevent function loss.

Detector To Control Unit :



Power Supply To Detector :

